## Make your own Ethernet Loopback connector

Occasionally I have the need for a network card to operate as though it has a live network connection, without it actually being connected to a network. Typically for testing purposes, and occasionally for specific software configurations. To do this I need a quick and easy way to make a loopback connector. Something small enough to keep in my PC toolkit, yet large enough that it won't be lost. Mine end up about the size of a ballpoint pen. The following is a quick "how to" for making an Ethernet loopback connector.

To build this particular loopback connector you will need one spare Category 5e (cat5) cable.

- 1. Cut 4 or 5 inches of the end off of a network cable, keeping the connector intact.
- 2. Cut away two inches of the main sheath covering the eight wires. (Be careful not to cut the wires inside.)
- 3. Cut the sheath on Orange-White and Green-White and twist them together. Tape this pair. (Soldering is recommended)
- 4. Cut the sheath on Green and Orange and twist them together. Tape this pair as well. (Soldering is recommended)
- 5. Cut the sheath on Blue and Brown-White and twist them together. Tape this pair as well. (Soldering is recommended)
- 6. Cut the sheath on Blue-White and Brown and twist them together. Tape this pair as well. (Soldering is recommended)
- 7. Tape the end down to make it look presentable.
- 8. Plug your new RJ-45 loopback into your Network Card.

